


AIROS TRUNCAL GARMENT SIZING GUIDE



Model	Inseam(cm)	Abdomen (cm)	Length (cm)	Ankle-Cir (cm)	Knee-Cir (cm)	Thigh-Cir (cm)	Waist-Cir (cm)	Belly-Cir (cm)	Abdomen-Cir (cm)
8-Chamber Small Pants (8-SP02) *	75.0	41.9	116.9	54.0	76.4	79.0	127.4	125.3	122.8
8-Chamber Small Pants XL (8-SPXL02)	75.4	41.5	116.9	53.0	79.0	88.0	155.0	155.7	155.7
8-Chamber Small Pants XXL (8-SPXXL02)	75.4	41.5	116.9	53.0	79.0	93.0	170.0	170.7	170.7
8-Chamber Medium Pants (8-MP02) *	83.8	42.5	126.3	65.2	80.0	82.0	127.6	123.8	122.0
8-Chamber Medium Pants XL (8-MPXL02)	83.8	42.4	126.2	64.0	82.0	90.0	155.0	155.9	155.9
8-Chamber Medium Pants XXL (8-MPXXL02)	83.8	42.4	126.2	64.0	82.0	95.0	170.0	171.0	171.0
8-Chamber Large Pants (8-LP02) *	94.7	47.4	142.1	71.0	93.1	95.0	148.3	145.2	143.0
8-Chamber Large Pants XL (8-LPXL02)	96.2	46.0	142.1	71.0	94.0	102.0	155.0	156.4	156.4
8-Chamber Large Pants XXL (8-LPXXL02)	96.2	46.0	142.1	71.0	94.0	110.0	170.0	171.1	171.2

New Pants Models & Measurements - (Rounded to the first decimal)

* Available in 6 chamber - for use with AIROS 6P