


AIROS TRUNCAL GARMENT SIZING GUIDE



Model (CODE)	Inseam (CM)	Abdomen Length (CM)	Total Length (CM)	Ankle Circ. (CM)	Knee Circ. (CM)	Thigh Circ. (CM)	Abdomen Circ. (CM)	Waist/Hip Circ. (CM)	Belly Circ. (CM)
8-Chamber Small Pants (8-SP) *	75	41.9	116.9	54	76.4	79	122.8	127.4	125.3
8-Chamber Small Pants XL (8-SPXL)	75.4	41.5	116.9	53	79	88	155.7	155	155.7
8-Chamber Small Pants XXL (8-SPXXL)	75.4	41.5	116.9	53	79	93	170.7	170	170.7
8-Chamber Medium Pants (8-MP) *	83.8	42.5	126.3	65.2	80	82	122	127.6	123.8
8-Chamber Medium Pants XL (8-MPXL)	83.8	42.4	126.2	64	82	90	155.9	155	155.9
8-Chamber Medium Pants XXL (8-MPXXL)	83.8	42.4	126.2	64	82	95	171	170	171
8-Chamber Large Pants (8-LP) *	94.7	47.4	142.1	71	93.1	95	143	148.3	145.2
8-Chamber Large Pants XL (8-LPXL)	96.1	46	142.1	71	94	102	156.4	155	156.4
8-Chamber Large Pants XXL (8-LPXXL)	96.1	46	142.1	71	94	110	171.2	170	171.1

New Pants Models & Measurements - (Rounded to the first decimal)

* Available in 6 chamber - for use with AIROS 6P